

SHEKNOWS

The ladies guide to

HOW TO

Change your Oil

stupid car problems



OIL



FUNNEL



GLOVES




OIL FILTER



DRAIN PAN




WRENCH



Allow oil to drain out completely.



Clean drain plug and replace by tightly screwing back on.



Remove the oil cap and the oil filter.



Tightly hold the filter over the drain pan and allow to drip.




Clean the oil filter off with rags.




Replace oil filter by using a bit of oil to screw into place with your hands.



Add new oil using funnel. It is best to place slightly less than the recommended amount.



Replace the cap and turn your car on for 30 seconds.



Take car off of jacks and check the oil amount.



Clean up your mess and take the used oil to a hazardous waste area.